









Unswag it

GET A LOGO OFF ELECTRONICS

ELECTRONICS



Unswag

MORE GUIDES AT UNSWAG.ME

Get a logo off electronics

A logo on a speaker, power bank, or earbuds case.

Written steps

1. Grab rubbing alcohol (70% or higher), a soft microfiber cloth, and cotton pads.
2. Power the device off and unplug it.
3. Put the alcohol on the cloth or pad, never directly on the device. The cloth should be damp, not wet.
4. Keep liquid away from charging ports, buttons, seams, and speaker grilles.
5. Rub the logo gently. If it starts to lift, keep going; if nothing happens after a minute or two, stop. Dry the surface right away.

When to skip removal: on battery packs, anything with an open seam, or anything you can't afford to damage, cover the logo with a sticker instead.

From Unswag: unswag.me/unswag/clean-electronics/